



Il colore italiano dal 1831

MICRO GRIT PRIMER

TECHNICAL DATA SHEET
COD. 7US002





SPECIAL PRIMER FOR DECORATIVE PASTES

- High-performance filling masking quartz primer optimized as a base coat before applying stucco paste such as Venetian plaster etc. Easy to apply, it allows an optimal preparation of the wall helping to uniform the support, to mask any small imperfections and to improve the adhesion of the plaster.

TYPICAL CHEMICAL AND PHYSICAL CHARACTERISTICS

APPEARANCE	Matt
COMPOSITION	Acrylic binders in emulsion, fillers with controlled granulometry
BROOKFIELD VISCOSITY	40.000 ± 5000 cP G6 V10 at 70°F
C.O.V. / V.O.C	Max. 50 g/L (0.42 lbs/gal).
COLOR	White

TYPICAL APPLICATION CHARACTERISTICS

	EFFECTIVE COVERAGE	250-300 sq ft / U.S. gal depending on the substrate
	DRYING (at 70°F and 65% R.H.)	Touch dry: 3-4 hours For re-coating: 24 hours
	DILUTION	Max 20% with water
	TOOLS	Brush, roller

APPLICATION SYSTEM

SUBSTRATES: Civil plaster, plasterwork, plasterboard, skim-coated walls, wood, etc., suitably prepared.

SUBSTRATE PREPARATION: Substrates must be sound, dry, clean, firm and free of damp patches and traces of dirt, grease, mold, etc. Remove flaking or chalky old paintwork by brushing or sanding. Serious imperfections, deficiencies, cracks and peeling must be removed and filled with Boero Water-Resistant Gypsum Powder.

In the case of chalky paint and surfaces, prepare the substrate with suitable fixative primer.



Il colore italiano dal 1831

MICRO GRIT PRIMER

COD. 7US002

RECOMMENDED APPLICATION TECHNIQUE

On firmly attached and fully dry substrate (we advise waiting at least 24 hours), apply a coat of *Micro Grit Primer* by roller or brush in order to obtain a rough surface to cover with the chosen plaster.

GENERAL INFORMATION AND NOTICES

Clean tools immediately after use with water.

Keep the product in a cool place and do not allow to freeze. Do not apply at temperatures below 40°F.

The technical information provided above is the result of careful laboratory testing and practical experience. Nevertheless, as the product is often used outside our control, we are unable to guarantee the quality of the end result. This information is subject to review by the Company.

CQ Rev. 1 - October 2018



Boero USA, Inc.
1209 Orange Street
Wilmington, DE 19801
800 935-6596
www.boerousa.com

MADE IN ITALY